

How to Install your new Wall Mounted Basin

Requirements: you will need access to a waste pipe & drainage.

Step 1; Assemble the bubbler head with connections provided and mount to basin.



Step 2; Assemble the waste seal to the basin.



Step 3; Mount the basin to the wall at the desired height using appropriate fixings and using the pre drilled holes.



Step 4; Using the compression fitting provided, connect to your water source as pictured below and push fit the desired amount of flexi-pipe



Step 5; Attach the drinking water supply to the bubbler head using the blue flexi pipe and connector.



Step 6; Attach the waste to the waste seal as shown in example.



Step 7; Turn on water and check for leaks.

WaterCoolers Direct.com Ltd offer this set of instructions as 'Guidance Only'. Therefore, WaterCoolers Direct.com Ltd and its employees or representatives cannot be held responsible for any work carried out by YOU and/or ANY third party using the instructions either in writing or over the telephone via the HelpDesk.